

ACアダプタセット販売対象機種

※対象機種は順次追加予定



Desktop

CA24I VN4640G	CA24V2 VN4660G	CX13 VN4670G	CX14 XC-730-F	RN96 XC-830
------------------	-------------------	-----------------	------------------	----------------

Notebook

A111-31	A114-31	A114-32	A315-21	A315-23
A315-32	A315-33	A315-34	A315-35	A315-41
A315-41G	A315-53	A315-54	A315-56	A315-58
A514-54	A515-51	A515-53	A515-54	A515-55
A515-56	A715-71G	A715-72G	A715-74G	AN515-44
AN515-52	AN515-54	AN515-55	AN515-56	AN515-57
AN517-51	AN517-52	C851T	C871T	CB311
CB314	CB315	CC315-72P	CC715	CN315
CN715	CP311	CP713	E5-576	ES1-332
ES1-523	ES1-533-W	EX215-51	EX215-52	EX215-54
EX2540	G3-572	PH315-51	PH315-52	PH315-53
PH315-54	PH517-51	PT315-53	PT515-51	PT515-52
PT715-51	R3-131T	SF113-31	SF114-32	SF313-51
SF313-51P	SF314-511	SF314-511P	SF314-54	SF314-56
SF314-57	SF314-59	SF316-51	SF514-52T	SF514-53T
SF514-54T	SF514-55T	SF515-51T	SF713-51-N	SF714-52T
SP111-32N	SP111-33	SP513-52N	SP714-51	TMB117M
TMB118G2R	TMB118G2RN	TMB118M	TMB118R	TMB311-31
TMB311R-31	TMB311RN-31	TMP238G2M	TMP238M	TMP2510G2M
TMP259G2M	TMP259M	TMV15-51	TMX3310M	TMX3410M
TMX514				

Chromebook

C721	C722	C731	C732	C732L
C732LT	C732T	C738T	C740	C851
C851T	CB311	CB314	CB315	CB3-532
CB5-132	CB715	CP311	CP511	CP513
CP5-471	CP713	CP713-1WN	R721T	R751T
R751TN	R752T	R752TN	R753T	R851T

Tablet

B1-790 SW512-52P	ET108-11A	ET110-31W	SA5-271P	SW312-31
---------------------	-----------	-----------	----------	----------



an acer brand

Notebook

NE336	NE574-F	NE574-S	NE575
-------	---------	---------	-------

Tablet

GW312-31

※リストに掲載ないモデルをご購入希望の方は、カスタマーサービスセンターまでご連絡下さい